

using No.10 adhesive

Preparation

The areas to be bonded need to be clean, dry and free from any dust, dirt or other contamination.

Adhesive Application

Use a spreader held at an angle of 60° or a brush to apply a thin coat of adhesive evenly to the back of both surfaces.

Allow the solvent to evaporate until the adhesive becomes touch dry before bringing the two coated surfaces together.

Apply pressure from the centre outwards to avoid trapping air, ensuring that good contact is made over the whole area.

Precautions

Correct positioning is essential as an immediate bond forms when the two surfaces are brought together.

When securing to stairs and steps, ensure that sufficient adhesive is applied. Coverings on stairs and steps must be firmly secured.

Read the safety data sheet for No.10 adhesive before using

treadmaster
flooring

treadmaster your partner for passenger transport

Contact us at www.treadmasterflooring.com or call +44 (0)1579 321 984

No PVC

Information in this document and otherwise supplied to users is based on our general experience and is given in good faith but because of particular factors which are outside our knowledge and control and affect the use of products, no warranty is given or implied with respect to such information. Specifications are subject to change without notice. Statements of operating limits quoted in this document are not an indication that these values can be simultaneously applied. A safe handling data sheet on this material is available on request.



Tiflex Limited, Tiflex House,
Liskeard, PL14 4NB, UK